

STM32F103C8T6			
+3V3	VBAT	3.3V2	+3V3
PC13_UNUSED	PC13	GND3	GND
PC14_UNUSED	PC14	5V	5V
PC15_UNUSED	PC15	PB9	GND
ENC_A	PA0	PB8	DISP_CHAR1
ENC_B	PA1	PB7	DISP_CHAR0
ENC_CLICK	PA2	PA2	DISP_CHAR3
FINE_TUNE_2	PA3	PA3	DISP_CHAR2
GATE	PA4	PA4	PB4_UNUSED
ADC_SCK	PA5	PA5	PB3_UNUSED
ADC_MISO	PA6	PA6	PA15_UNUSED
ADC_MOSI	PA7	PA7	PA12_UNUSED
ADC_SS	PA0	PA11	PA11_UNUSED
DISP_SER	PB1	PA10	BX
DISP_EN	PB10	PA9	TX
DISP_SCK	PB11	PA8	PA8_UNUSED
RESET	RESET	PB15	DAC_MOSI
+3V3_2	3.3V	PB14	PA14_UNUSED
ONBOARD	GND	PB13	DAC_SCK
ONBOARD2	GND2	PB12	DAC_SS





